



VALLE SHIELD ASSEMBLY INSTRUCTIONS

(View at www.thevalleshield.com)

1. After removing The Shield's frame from the box, take the first back leg and slide it into the bottom of the frame, making sure the wheel is on the rear side of the screen. Secure into place by using two of the bolts and lock nuts. Tighten until secure.
2. Rotate the screen and then repeat the process with the second leg. Make certain the leg and frame numbers align. With legs attached, place the frame in upright position.
3. Screw in the front rods into the upper-left and upper-right corners. Either of the rods fit into either corner of the frame. We recommend that you use a wrench to make certain that the rods are snug.
4. Lift the front hanging net with springs and slide it over the two front rods, matching the numbers on the springs and frame. The net will fall into place, barely touching the ground, covering the metal frame and preventing it from being struck by ball.

ACCESSORIES ASSEMBLY INSTRUCTIONS

OVERHEAD PROTECTOR

Screw the rear rods into the upper-right and upper-left corners. Use a wrench to make certain that the rods are snug. Slide the overhead protector over the attached rear rods. Secure by wrapping the two Velcro strips around the frame & the overhead protector.

THE WING

Insert the downward angled hinges of the wing accessory into the slots on either the left or right side. Wing will automatically lock into place.

THE SIDE PROTECTOR

Insert the downward angled hinges of the Side Protector into the slots on the desired side of the frame.

THE BALL HOLDER

Place the ball holder's downward angle hinges on the center support beam of the frame.

THE SHIELD CORDS

For windy outdoor conditions, secure the front net by hooking the Shield Cords to the exterior loops on the front legs and the chain on the front net. Do not tighten the net so much that the upper-front springs are bent.

Visit

THEVALLESHIELD.COM

For Video Assembly Instructions